




for a greener tomorrow



**MITSUBISHI
ELECTRIC**

Changes for the Better

FACTORY AUTOMATION

Mitsubishi Servo System Controllers
Quick Start Guide

Let's Start!

Quick Start Guide

MELSEC iQ-R Series Simple Motion Module



MELSEC iQ-R
series

Applicable Model

- RD77MS2
- RD77MS4
- RD77MS8
- RD77MS16

SAFETY PRECAUTIONS (Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. Refer to the user's manual of the CPU module to use for a description of the PLC system safety precautions.

In this manual, the safety precautions are classified into two levels: "⚠️WARNING" and "⚠️CAUTION".

| | |
|--|---|
|  WARNING | Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury. |
|  CAUTION | Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage. |

Under some circumstances, failure to observe the precautions given under "⚠️CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

[Design Precautions]

WARNING

- Configure safety circuits external to the programmable controller to ensure that the entire system operates safely even when a fault occurs in the external power supply or the programmable controller. Failure to do so may result in an accident due to an incorrect output or malfunction.
 - (1) Configure external safety circuits, such as an emergency stop circuit, protection circuit, and protective interlock circuit for forward/reverse operation or upper/lower limit positioning.
 - (2) The programmable controller stops its operation upon detection of the following status, and the output status of the system will be as shown below.
 - Turned off if the overcurrent or overvoltage protection of the power supply module is activated.
 - Held or turned off according to the parameter setting if the self-diagnostic function of the CPU module detects an error such as a watchdog timer error.
 - (3) Also, all outputs may be turned on if an error occurs in a part, such as an I/O control part, where the CPU module cannot detect any error. To ensure safety operation in such a case, provide a safety mechanism or a fail-safe circuit external to the programmable controller. For a fail-safe circuit example, refer to the user's manual of the CPU module to use.
 - (4) Outputs may remain on or off due to a failure of a component such as a relay and transistor in an output circuit. Configure an external circuit for monitoring output signals that could cause a serious accident.
- In an output circuit, when a load current exceeding the rated current or an overcurrent caused by a load short-circuit flows for a long time, it may cause smoke and fire. To prevent this, configure an external safety circuit, such as a fuse.
- Configure a circuit so that the programmable controller is turned on first and then the external power supply. If the external power supply is turned on first, an accident may occur due to an incorrect output or malfunction.
- For the operating status of each station after a communication failure, refer to manuals relevant to the network. Incorrect output or malfunction due to a communication failure may result in an accident.

WARNING

- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
- Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
- Do not write any data to the "system area" and "write-protect area" of the buffer memory in the module. Also, do not use any "use prohibited" signals as an output signal from the CPU module to each module. Doing so may cause malfunction of the programmable controller system. For the "system area", "write-protect area", and the "use prohibited" signals, refer to the user's manual for the module used.
- If a communication cable is disconnected, the network may be unstable, resulting in a communication failure of multiple stations. Configure an interlock circuit in the program to ensure that the entire system will always operate safely even if communications fail. Failure to do so may result in an accident due to an incorrect output or malfunction.
- To maintain the safety of the programmable controller system against unauthorized access from external devices via the network, take appropriate measures. To maintain the safety against unauthorized access via the Internet, take measures such as installing a firewall.
- Configure safety circuits external to the programmable controller to ensure that the entire system operates safely even when a fault occurs in the external power supply or the programmable controller. Failure to do so may result in an accident due to an incorrect output or malfunction.
 - (1) Machine home position return is controlled by two kinds of data: a home position return direction and a home position return speed. Deceleration starts when the near-point dog signal turns on. If an incorrect home position return direction is set, motion control may continue without deceleration. To prevent machine damage caused by this, configure an interlock circuit external to the programmable controller.
 - (2) When the module detects an error, the motion slows down and stops or the motion suddenly stops, depending on the stop group setting in parameter. Set the parameter to meet the specifications of a positioning control system. In addition, set the home position return parameter and positioning data within the specified setting range.
 - (3) Outputs may remain on or off, or become undefined due to a failure of a component such as an insulation element and transistor in an output circuit, where the module cannot detect any error. In a system that the incorrect output could cause a serious accident, configure an external circuit for monitoring output signals.
- If safety standards (ex., robot safety rules, etc.) apply to the system using the module, servo amplifier and servomotor, make sure that the safety standards are satisfied.
- Construct a safety circuit externally of the module or servo amplifier if the abnormal operation of the module or servo amplifier differs from the safety directive operation in the system.
- Do not remove the SSCNETIII cable while turning on the control circuit power supply of Multiple CPU system and servo amplifier. Do not see directly the light generated from SSCNETIII connector of the module or servo amplifier and the end of SSCNETIII cable. When the light gets into eyes, you may feel something wrong with eyes. (The light source of SSCNETIII complies with class1 defined in JISC6802 or IEC60825-1.).

[Design Precautions]

CAUTION

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100 mm or more between them. Failure to do so may result in malfunction due to noise.
- During control of an inductive load such as a lamp, heater, or solenoid valve, a large current (approximately ten times greater than normal) may flow when the output is turned from off to on. Therefore, use a module that has a sufficient current rating.
- After the CPU module is powered on or is reset, the time taken to enter the RUN status varies depending on the system configuration, parameter settings, and/or program size. Design circuits so that the entire system will always operate safely, regardless of the time.
- Do not power off the programmable controller or do not reset the CPU module during the setting registration. Doing so will make the data in the flash ROM undefined. The data need to be set in the buffer memory and to be written to the flash ROM again. Doing so may cause malfunction or failure of the module.
- Reset the CPU module after changing the parameters. Failure to do so may cause malfunction because the previous parameter settings remain in the module.
- When changing the operating status of the CPU module from external devices (such as remote RUN/STOP), select "Do Not Open by Program" for "Opening Method" in the module parameters. If "Open by Program" is selected, an execution of remote STOP causes the communication line to close. Consequently, the CPU module cannot reopen the communication line, and external devices cannot execute the remote RUN.

[Installation Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may result in electric shock or cause the module to fail or malfunction.

[Installation Precautions]

CAUTION

- Use the programmable controller in an environment that meets the general specifications in the manual "Safety Guidelines" included in the base unit. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- To mount a module, place the concave part(s) located at the bottom onto the guide(s) of the base unit, and push in the module until the hook(s) located at the top snaps into place. Incorrect mounting may cause malfunction, failure, or drop of the module.
- When using the programmable controller in an environment of frequent vibrations, fix the module with a screw.
- Tighten the screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- When using an extension cable, connect it to the extension cable connector of the base unit securely. Check the connection for looseness. Poor contact may cause incorrect input or output.
- When using an SD memory card, fully insert it into the memory card slot. Check that it is inserted completely. Poor contact may cause malfunction.
- Securely insert an extended SRAM cassette into the cassette connector of a CPU module. After insertion, close the cassette cover and check that the cassette is inserted completely. Poor contact may cause malfunction.
- Do not directly touch any conductive parts and electronic components of the module, SD memory card, extended SRAM cassette, or connector. Doing so may cause malfunction or failure of the module.

[Wiring Precautions]

WARNING

- Shut off the external power supply (all phases) used in the system before installation and wiring. Failure to do so may result in electric shock or damage to the product.
- After installation and wiring, attach the included terminal cover to the module before turning it on for operation. Failure to do so may result in electric shock.

[Wiring Precautions]

CAUTION

- Individually ground the FG and LG terminals of the programmable controller with a ground resistance of 100 ohm or less. Failure to do so may result in electric shock or malfunction.
- Use applicable solderless terminals and tighten them within the specified torque range. If any spade solderless terminal is used, it may be disconnected when the terminal screw comes loose, resulting in failure.
- Check the rated voltage and signal layout before wiring to the module, and connect the cables correctly. Connecting a power supply with a different voltage rating or incorrect wiring may cause fire or failure.
- Connectors for external devices or coaxial cables must be crimped or pressed with the tool specified by the manufacturer, or must be correctly soldered. Incomplete connections may cause short circuit, fire, or malfunction.
- Securely connect the connector to the module. Poor contact may cause malfunction.
- Do not install the control lines or communication cables together with the main circuit lines or power cables. Keep a distance of 100 mm or more between them. Failure to do so may result in malfunction due to noise.
- Place the cables in a duct or clamp them. If not, dangling cable may swing or inadvertently be pulled, resulting in damage to the module or cables or malfunction due to poor contact. Do not clamp the extension cables with the jacket stripped.
- Check the interface type and correctly connect the cable. Incorrect wiring (connecting the cable to an incorrect interface) may cause failure of the module and external device.
- Tighten the terminal screws or connector screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, fire, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, fire, or malfunction.
- When disconnecting the cable from the module, do not pull the cable by the cable part. For the cable with connector, hold the connector part of the cable. For the cable connected to the terminal block, loosen the terminal screw. Pulling the cable connected to the module may result in malfunction or damage to the module or cable.
- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring. Do not remove the film during wiring. Remove it for heat dissipation before system operation.
- Mitsubishi programmable controllers must be installed in control panels. Connect the main power supply to the power supply module in the control panel through a relay terminal block. Wiring and replacement of a power supply module must be performed by qualified maintenance personnel with knowledge of protection against electric shock. For wiring, refer to the MELSEC iQ-R Module Configuration Manual.
- For Ethernet cables to be used in the system, select the ones that meet the specifications in the MELSEC iQ-R Ethernet/CC-Link IE User's Manual (Startup). If not, normal data transmission is not guaranteed.

[Startup and Maintenance Precautions]

WARNING

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
- Correctly connect the battery connector. Do not charge, disassemble, heat, short-circuit, solder, or throw the battery into the fire. Also, do not expose it to liquid or strong shock. Doing so may cause the battery to generate heat, explode, ignite, or leak, resulting in injury or fire.
- Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws, connector screws, or module fixing screws. Failure to do so may result in electric shock or cause the module to fail or malfunction.

[Startup and Maintenance Precautions]

CAUTION

- When connecting an external device with a CPU module or intelligent function module to modify data of a running programmable controller, configure an interlock circuit in the program to ensure that the entire system will always operate safely. For other forms of control (such as program modification, parameter change, forced output, or operating status change) of a running programmable controller, read the relevant manuals carefully and ensure that the operation is safe before proceeding. Improper operation may damage machines or cause accidents.
- Especially, when a remote programmable controller is controlled by an external device, immediate action cannot be taken if a problem occurs in the programmable controller due to a communication failure. To prevent this, configure an interlock circuit in the program, and determine corrective actions to be taken between the external device and CPU module in case of a communication failure.
- Do not disassemble or modify the modules. Doing so may cause failure, malfunction, injury, or a fire.
- Use any radio communication device such as a cellular phone or PHS (Personal Handyphone System) more than 25 cm away in all directions from the programmable controller. Failure to do so may cause malfunction.
- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may cause the module to fail or malfunction.
- Tighten the screws within the specified torque range. Undertightening can cause drop of the component or wire, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- After the first use of the product, do not mount/remove the module to/from the base unit, and the terminal block to/from the module, and do not insert/remove the extended SRAM cassette to/from the CPU module more than 50 times (IEC 61131-2 compliant) respectively. Exceeding the limit of 50 times may cause malfunction.
- After the first use of the product, do not insert/remove the SD memory card to/from the CPU module more than 500 times. Exceeding the limit may cause malfunction.
- Do not touch the metal terminals on the back side of the SD memory card. Doing so may cause malfunction or failure.
- Do not touch the integrated circuits on the circuit board of an extended SRAM cassette. Doing so may cause malfunction or failure.
- Do not drop or apply shock to the battery to be installed in the module. Doing so may damage the battery, causing the battery fluid to leak inside the battery. If the battery is dropped or any shock is applied to it, dispose of it without using.

- Startup and maintenance of a control panel must be performed by qualified maintenance personnel with knowledge of protection against electric shock. Lock the control panel so that only qualified maintenance personnel can operate it.
- Before handling the module, touch a conducting object such as a grounded metal to discharge the static electricity from the human body. Failure to do so may cause the module to fail or malfunction.
- Before testing the operation, set a low speed value for the speed limit parameter so that the operation can be stopped immediately upon occurrence of a hazardous condition.
- Confirm and adjust the program and each parameter before operation. Unpredictable movements may occur depending on the machine.
- When using the absolute position system function, on starting up, and when the module or absolute value motor has been replaced, always perform a home position return.
- Before starting the operation, confirm the brake function.
- Do not perform a megger test (insulation resistance measurement) during inspection.
- After maintenance and inspections are completed, confirm that the position detection of the absolute position detection function is correct.
- Lock the control panel and prevent access to those who are not certified to handle or install electric equipment.

[Operating Precautions]

CAUTION

- When changing data and operating status, and modifying program of the running programmable controller from an external device such as a personal computer connected to an intelligent function module, read relevant manuals carefully and ensure the safety before operation. Incorrect change or modification may cause system malfunction, damage to the machines, or accidents.
- Do not power off the programmable controller or reset the CPU module while the setting values in the buffer memory are being written to the flash ROM in the module. Doing so will make the data in the flash ROM undefined. The values need to be set in the buffer memory and written to the flash ROM again. Doing so also can cause malfunction or failure of the module.
- Note that when the reference axis speed is specified for interpolation operation, the speed of the partner axis (2nd, 3rd, or 4th axis) may exceed the speed limit value.
- Do not go near the machine during test operations or during operations such as teaching. Doing so may lead to injuries.

[Operating Precautions]

CAUTION

- When disposing of this product, treat it as industrial waste.
- When disposing of batteries, separate them from other wastes according to the local regulations. For details on battery regulations in EU member states, refer to the MELSEC iQ-R Module Configuration Manual.

[Transportation Precautions]

CAUTION

- When transporting lithium batteries, follow the transportation regulations. For details on the regulated models, refer to the MELSEC iQ-R Module Configuration Manual.
- The halogens (such as fluorine, chlorine, bromine, and iodine), which are contained in a fumigant used for disinfection and pest control of wood packaging materials, may cause failure of the product. Prevent the entry of fumigant residues into the product or consider other methods (such as heat treatment) instead of fumigation. The disinfection and pest control measures must be applied to unprocessed raw wood.

CONTENTS

| | |
|---|-----------------|
| SAFETY PRECAUTIONS | 1 |
| CONTENTS..... | 9 |
| 1. OVERVIEW..... | 1 to 12 |
| 1.1 Simple Motion Module Features..... | 11 |
| 1.2 Relevant Manuals | 11 |
| 2. MODULE STARTUP | 13 to 20 |
| 2.1 System Configuration | 14 |
| 2.2 Device Preparation | 15 |
| 2.3 Startup Procedure..... | 16 |
| 2.4 Installation of Modules..... | 17 |
| 2.5 Wiring and Cable Connection..... | 18 |
| 3. POSITIONING CONTROL SYSTEM STARTUP | 21 to 42 |
| 3.1 Creating a New Project..... | 21 |
| 3.2 Sequence Program Creation | 23 |
| 3.3 Parameter Settings for Simple Motion Module..... | 29 |
| 3.4 Operation Check..... | 36 |
| 3.4.1 JOG operation | 36 |
| 3.4.2 Home position return (Establishment of the home position) | 39 |
| 3.4.3 Positioning control | 41 |
| 4. SYNCHRONOUS CONTROL STARTUP | 43 to 60 |
| 4.1 System Configuration | 44 |
| 4.2 Startup Procedure for Synchronous Control | 45 |
| 4.3 Parameter Creation for Synchronous Control | 46 |
| 4.3.1 System configuration settings | 46 |
| 4.3.2 Parameters and servo parameters settings | 46 |
| 4.3.3 Positioning data settings | 47 |
| 4.3.4 Synchronous control parameter settings..... | 48 |
| 4.3.5 Cam data creation | 52 |
| 4.3.6 Saving a project..... | 53 |
| 4.3.7 Writing to the Simple Motion module..... | 53 |
| 4.4 Operation Check for Synchronous Control..... | 54 |
| 4.4.1 Home position return | 54 |
| 4.4.2 Synchronous control start..... | 55 |
| 4.4.3 Operation check with digital oscilloscope..... | 58 |
| APPENDICES..... | 61 to 72 |
| Appendix 1 Simulation..... | 61 |
| Appendix 2 Parameter and Positioning Data | 65 |
| Appendix 3 Sample Program..... | 68 |

1. OVERVIEW

This document describes necessary items and operation for first-time users of the Simple Motion module to make wiring, perform JOG operation, program operation, and synchronous control with Programmable Controller Engineering Software, MELSOFT GX Works3. Refer to related manuals, where necessary, to fully utilize capability of each module.

1.1 Simple Motion Module Features

1. A wide range of controls, such as positioning, advanced synchronous, cam, speed-torque controls, are available.
2. Advanced, extensive controls can be achieved just with function blocks (FB) and sequence programs.
3. Programming, Servo adjustment, operation and maintenance can be all covered by MELSOFT GX Works3 only.
4. The Simple Motion module can be connected to SSCNET III/H compatible, high-performance servo amplifiers.

1.2 Relevant Manuals

(1) Simple Motion module

| Name | Number |
|--|------------|
| MELSEC iQ-R Simple Motion Module User's Manual (Startup) This manual explains specifications, procedures before operation, system configuration, wiring, and operation examples of the Simple Motion module. | IB-0300245 |
| MELSEC iQ-R Simple Motion Module User's Manual (Application) This manual explains functions, input/output signals, buffer memories, parameter settings, programming, and troubleshooting of the Simple Motion module. | IB-0300247 |
| MELSEC iQ-R Simple Motion Module User's Manual (Advanced Synchronous Control) This manual explains functions and programming for the synchronous control of the Simple Motion module. | IB-0300249 |

(2) MELSEC iQ-R series PLC

| Name | Number |
|---|-----------|
| MELSEC iQ-R CPU Module User's Manual (Startup) This manual explains the specifications of the CPU module, procedures before operation, and procedures for troubleshooting. | SH-081263 |
| MELSEC iQ-R CPU Module User's Manual (Application) This manual explains the basic knowledge required for program design, CPU module functions, devices/labels, parameters etc. | SH-081264 |
| MELSEC iQ-R Module Configuration Manual This manual explains the specifications of the power supply modules, base units, SD memory cards etc., and the mounting environment and mounting position. | SH-081262 |

- 1 Overview
- 2 Module Startup
- 3 Positioning Control Startup
- 4 Synchronous Control Startup
- Appendices


(3) Servo amplifier

| Name | Number |
|---|-----------|
| MR-J4-_B(-RJ) Servo amplifier Instruction Manual This manual explains the I/O signals, parts names, parameters, start-up procedure and others for MR-J4-_B(-RJ)/MR-J4-_B4(-RJ)/MR-J4-_B1(-RJ) Servo amplifier. | SH-030106 |
| MR-J4W2-_B/MR-J4W3-_B/MR-J4W2-0303B6 Servo amplifier Instruction Manual This manual explains the I/O signals, parts names, parameters, start-up procedure and others for Multi-axis AC Servo MR-J4W2-_B/MR-J4W3-_B/MR-J4W2-0303B6 Servo amplifier. | SH-030105 |

2. MODULE STARTUP

A 1-axis system with ball screw is used as an example in Chapter 2 to 3.

<Machine>




<Specifications>

- Ball screw lead (PB) : 10000.0 μ m (=10mm)
- Reduction ratio (NL/NM) : 1/2 (Load side [NL]/Motor side [NM])
The load-side ball screw is made to rotate once by rotating the motor twice.
- Encoder resolution : 4194304 [pulse/rev]
- Servo amplifier : MR-J4-10B
- Servo motor : HG-KR series


<Operation pattern>

- (1) The workpiece travels from home position to P1 back and forth.
 1. It moves at 2000.00mm/min from home position (0 mm) to P1.
 2. It moves at 8000.00mm/min from P1 to the home position.
- (2) Continuous positioning of 1. through 2. is performed.

<Position [mm]>




<Speed [mm/min]>





2.1 System Configuration

The following shows a system example using the Simple Motion module, MR-J4-10B, and a servo motor.



2.2 Device Preparation

Prepare the following devices, cables, and software.

| | | | |
|---|---|---|---|
| <p>Simple Motion module RD77MS4</p>  | <p>Engineering Software MELSOFT GX Works3</p>  | | |
| <p>Servo amplifier MR-J4-10B</p>  | <p>Servo motor HG-KR13</p>  | | |
| <p>Main base unit R35B</p>  | <p>Power supply module R61P</p>  | <p>PLC CPU module R04CPU</p>  | <p>Input/output module RX42C4 (Input) RY42NT2P (Output)</p>  |
| <p>Encoder cable</p>  | <p>Servo motor power cable</p>  | <p>SSCNET III cable MR-J3BUS_M</p>  | <p>USB cable</p>  |
| <p>Molded-case circuit breaker (MCCB)</p>  | <p>Magnetic contactor (MC)</p>  | <p>Circuit protector (CP)</p>  | |

2.3 Startup Procedure

The following sections explain operation details and procedures required for system startup.

2. MODULE STARTUP

2.1 System configuration

2.2 Device preparation

2.3 Startup procedure

2.4 Installation of modules

(1) Installing a battery

(2) Inserting an extended SRAM cassette and a SD memory card

(3) Installing a module

2.5 Wiring and cable connection

(1) Wiring for power supply module

(2) Wiring for servo amplifier power supply and servo motor power cables

(3) Axis selection rotary switch of servo amplifier

(4) Connection of each cable

(5) Power-on of the system

(6) Power-on of servo amplifier

3. POSITIONING CONTROL STARTUP

3.1 Creating a new project

(1) Installing engineering software

(2) Creating a new project

(3) Connecting the PLC CPU to a personal computer

(4) Initializing the PLC CPU module

(5) Settings for sequence program parameters

3.2 Sequence program creation

(1) New sequence programs creation

(2) Multiple comments display setting

(3) Registration of global labels

(4) Element selection window

(5) Sequence program creation with labels

(6) Sequence program creation with module FB

(7) Saving a project

(8) Writing to PLC CPU

3.3 Parameter settings for Simple Motion module

(1) Start of Simple Motion module setting function

(2) System settings

(3) Parameter settings

(4) Servo parameter settings

(5) Positioning data setting

(6) Saving a project

(7) Writing to the Simple Motion module

3.4 Operation check

3.4.1 JOG operation

3.4.2 Home position return (Establishment of the home position)

3.4.3 Positioning control


2.4 Installation of Modules

Install the modules.



(1) Installing a battery

The connector plug of the Q6BAT is disconnected from the jack of the CPU module before shipment. To use the battery, connect the connector, following the procedure below.



1. Open the battery cover located on the bottom of the CPU module.
2. Check that the Q6BAT (1) is correctly installed.
3. Check the direction and securely insert the connector plug of the Q6BAT (2) to the jack (3) of the CPU module.
4. Close the battery cover.

(2) Inserting an extended SRAM cassette and a SD memory card

Since the example system does not use an extended SRAM cassette and a SD memory card, the insertion/removal procedures are omitted in this document. Refer to MELSEC iQ-R CPU Module User's Manual (Startup) for details.

(3) Installing a module

Install each module to the main base unit.

Refer to MELSEC iQ-R Module Configuration Manual for details.

2.5 Wiring and Cable Connection

The following shows the wiring and cable connection example for the Simple Motion module and servo amplifiers.

The system below uses the cables for MR-J4-10B. If the capacity of the servo amplifier is different, refer to SERVO AMPLIFIER INSTRUCTION MANUAL for each model.

(1) Wiring for power supply module


The following shows an example when a power wire and a grounding wire are connected to the power supply module. Connect an isolation transformer when noise often enters in the power supply system.

| Item | Applicable wire size | Tightening torque |
|----------------|---|-------------------|
| Power wire | 0.75 to 2mm ² (AWG18 to AWG14) | 1.02 to 1.38N·m |
| Grounding wire | 0.75 to 2mm ² (AWG18 to AWG14) | 1.02 to 1.38N·m |

(2) Wiring for servo amplifier power supply and servo motor power cables

Wire the control circuit power supply (L11, L21) and the main circuit power supply (L1, L2, L3) of the servo amplifier, and the servo motor power cable.



| Item | Applicable wire size | Tightening torque |
|---|-----------------------------|-------------------|
| Control circuit power supply (L11, L21) | 1.25mm ² (AWG16) | - |
| Main circuit power supply (L1, L2, L3) | 2mm ² (AWG14) | - |
| Grounding wire | 1.25mm ² (AWG16) | 1.2N·m |



(3) Axis selection rotary switch of servo amplifier

"0" to "F" of the axis selection rotary switch correspond to "d01" to "d16".

The following table shows the correspondence between SSCNET configuration and the switch No. Set the switch correctly checking the correspondence.

| Servo amplifier MR-J4-10B | | Description | | | | |
|---|-----|---|----------|-----|------|----------|
|  <p>Axis selection rotary switch</p> | No. | dno. | Axis No. | No. | dno. | Axis No. |
| | "0" | d01 | Axis 1 | "8" | d08 | - |
| | "1" | d02 | Axis 2 | "9" | d09 | - |
| | "2" | d03 | Axis 3 | "A" | d10 | - |
| | "3" | d04 | Axis 4 | "B" | d11 | - |
| | "4" | d05 | - | "C" | d12 | - |
| | "5" | d06 | - | "D" | d13 | - |
| | "6" | d07 | - | "E" | d14 | - |
| "7" | d08 | - | "F" | d15 | - | |
| | |  <p>SSCNET configuration</p> | | | | |

(4) Connection of each cable

Connect the SSCNET III cable, the encoder cable, and the servo motor power cable. For between the personal computer and PLC CPU, connect a USB cable.

(5) Power-on of the system

1. Check the wiring for the power supply module.
2. Confirm that the PLC CPU is in STOP status.
3. Turn ON the power of PLC CPU.



(a) Power supply module: LED (green light) turns ON.

(b) CPU module: READY LED (green light) turns ON.

When parameters and programs are not written to the CPU module, the ERROR LED (red light) of the PLC CPU flickers, but no immediate error is occurring. After writing parameters and programs and turning the power OFF to ON, the ERROR LED will be OFF.

(6) Power-on of servo amplifier

Turn the power ON after checking the following items.

1. Check the wiring for servo amplifier.
2. Turn the servo amplifier ON.

The communication status with the Simple Motion module can be checked on the display.

| Servo amplifier | LED display | Status | Description | Wiring result |
|---|-------------|--------------------------------|--|-----------------------|
|  | AA | Initializing standby | The power supply of servo system controller is turned off while the power supply of servo amplifier is on. | Normal |
| | Ab | Initializing | During initial setting for communication specifications. | |
| | AC | Initializing | Initial setting for communication specifications has completed, and then the servo amplifier has been synchronized with the servo system controller. | |
| | Ad | Initializing | During communication with the servo system controller for initial parameter setting | |
| | AE | Initializing | During communication with the servo system controller for the servo motor/encoder information | |
| | AF | Initializing | During communication with servo system controller for initial signal data | |
| | AH | Initializing completion | The process for initial data communication with the servo system controller is completed. | |
| | b01 | Ready-off | The ready-off command from the servo system controller was received. | |
| | C01 | Servo-off | The servo-off command from the servo system controller was received. | |
| | d01 | Servo-on | The servo-on command from the servo system controller was received. | |
| | E6.1 | Forced stop warning | Forced stop warning | |
| | E7.1 | Controller forced stop warning | Controller forced stop warning | |
| | OFF | - | - | Control power is off. |

<Actions>

- When parameters are not written to the Simple Motion module, the LED displays "AA" or "Ab", but no immediate error is occurring. In this case, write parameters.
- If the LED turns OFF, check the wiring for control power supply.

3. POSITIONING CONTROL STARTUP

3.1 Creating a New Project

(1) Installing engineering software


Install MELSOFT iQ Works or MELSOFT GX Works3, following the Installation Instruction provided with the software package.

| Product | Model | Description |
|-------------------|---------------|--|
| MELSOFT iQ Works | SW2DND-iQWK-E | FA Engineering Software - System Management Software [MELSOFT Navigator] - Programmable Controller Engineering Software [MELSOFT GX Works3] - Motion Controller Engineering Software [MELSOFT MT Works2] - Screen Design Software [MELSOFT GT Works3] - Robot Total Engineering Support Software [MELSOFT RT ToolBox2 mini] - Inverter Setup Software [MELSOFT FR Configurator2] |
| MELSOFT GX Works3 | SW1DND-GXW3-E | Simple Motion module parameter settings, sequence program creation |

Note) The screen windows in this document may differ from the ones you use.
 (The system uses "MELSOFT GX Works3 Version 1.007H")


(2) Creating a new project

Start MELSOFT GX Works3, and create a new project.



[Project] → [New]


Series : RCPU
 Model : R04 (specify the CPU to be used)
 Program language : Ladder



The window asking about module label addition appears.
 Click [Yes].

(3) Connecting the PLC CPU to a personal computer

Confirm the connection between a personal computer and the PLC CPU.




1. Connect the CPU module to a personal computer.
2. Select [Online] → [Specify Connection Destination] to open the [Specify Connection Destination Connection] window.
3. Select "CPU Module Direct Coupled Setting".
4. Select the connection method with CPU module.

(4) Initializing the PLC CPU module

Initialize a memory of the PLC CPU.


Click [Initialization] on the Memory Management window.





(5) Settings for sequence program parameters

Set the system parameter and each module parameter.


<Creating a module configuration>



1. Select the main base unit, CPU, I/O, and Simple Motion module to be used from the POU list, and drag & drop them to the configuration screen.
2. Select [Edit] - [Parameter] - [Fix] in the menu.
3. The window asking about module label addition appears for the selected modules. Click "Yes".
4. Double click on the Simple Motion module to open the Simple Motion Module Setting Function screen.
5. Set the parameters, and close it when finished.



4.



5.

3.2 Sequence Program Creation


The use of label and function block (FB) removes the need to remember devices when programming.

(1) New sequence programs creation

Appendix 3 provides the sequence program example.

(2) Multiple comments display setting

Check the "Enable Multiple Comments Display" box and "Target" boxes for each language to switch the language for comments in sequence programs.




- 1
- Overview
- 2
- Module Startup
- 3
- Positioning Control Startup
- 4
- Synchronous Control Startup
- Appendices

(3) Registration of global labels

Labels are variable elements that allow you to put arbitrary names or data types to programs, etc. The use of labels allows you to create a program without worries about devices and buffer memory, enabling a different model/product to be used with the same program.

1. Select [Label] → [Global]. The global label registration window appears.
2. Register the global label, referring to the table below.




<Global label setting examples>

| Label Name | Data type | Class | Device | Description |
|----------------------------|--------------------------|------------|--------|------------------------------------|
| bDuringJOGInchingOperation | Bit | VAR_GLOBAL | M81 | JOG/Inching Operation flag |
| bJogEND | Bit | VAR_GLOBAL | M82 | JOG End Flag |
| bJogOK | Bit | VAR_GLOBAL | M83 | JOG OK flag |
| bJogERR | Bit | VAR_GLOBAL | M84 | JOG Error flag |
| bStartEND | Bit | VAR_GLOBAL | M85 | Positioning Start Operation flag |
| bStartOK | Bit | VAR_GLOBAL | M86 | Positioning Start OK |
| bStartERR | Bit | VAR_GLOBAL | M87 | Positioning Start Error |
| bPositioningStartReq | Bit | VAR_GLOBAL | M80 | Positioning Start Request |
| iAxisNo | Word [with signs] | VAR_GLOBAL | D14 | Axis No |
| uwPositioningStartNo | Word [with signs] | VAR_GLOBAL | D16 | Positioning Start No |
| i_JogSpeedData | Double word [with signs] | VAR_GLOBAL | D10 | Jog Speed data memo |
| uwErrId | Word [with signs] | VAR_GLOBAL | D12 | JOG Error code |
| bJogSpeedReq | Bit | VAR_GLOBAL | X60 | JOG Speed Req |
| bAxis1 | Bit | VAR_GLOBAL | X61 | Axis 1 |
| bAxis2 | Bit | VAR_GLOBAL | X62 | Axis 2 ^(Note-1) |
| bHomePositionData | Bit | VAR_GLOBAL | X63 | Home Position return Data |
| bPositioningStartData | Bit | VAR_GLOBAL | X65 | Positioning Start Data |
| bSyncPosiStartData | Bit | VAR_GLOBAL | X66 | Synchronous Positioning Start data |
| bJogForwardReq | Bit | VAR_GLOBAL | X6E | JOG Forward Start req |
| bJogReverseReq | Bit | VAR_GLOBAL | X6F | JOG Reverse Start Req |
| bStartpositioning | Bit | VAR_GLOBAL | X71 | Start Positioning req |
| bServoON | Bit | VAR_GLOBAL | X7B | Servo ON req |
| bErrorReset | Bit | VAR_GLOBAL | X7E | Error reset |
| bStopSwitch | Bit | VAR_GLOBAL | X7F | Stop |
| bSynchronous | Bit | VAR_GLOBAL | X7D | Synchronous Axis Set |

(Note-1): The labels above are for the synchronous control system in Chapter 4.


(4) Element selection window

1. Select [View] → [Docking Window] → [Element Selection].
2. Select [Module] tab in the Element Selection window, and Module Label and Module FB are displayed.




(5) Sequence program creation with module labels

1. Select [Module Label].
2. Select a label from the module label list.
3. Drag & drop the module label.
4. Change the contact to an arbitrary contact or coil by double-clicking it.
5. Click [OK] to create a circuit.
6. Select [Convert] → [Convert] in the menu.




- 1 Overview
- 2 Module Startup
- 3 Positioning Control Startup
- 4 Synchronous Control Startup
- Appendices


- (6) Sequence program creation with module FB
 1. Drag & drop a necessary module FB.
 2. "FB Instance Name" window appears.
Select whether the instance is registered as a global label or a local label, and input an instance name.
 3. Double click on where a circuit addition is made.
 4. Select a circuit symbol, and enter variables.
 5. Click [OK], and the "Input Comment" window appears.
 6. After inputting comments, click [OK].
 7. Move the cursor to where the circuit is added, and double click there.
 8. Click [OK], and the circuit is created.



9. Drag & drop "RD77_1" in the [Module Label]. The module label is written.
10. Create another circuit in the same manner and select [F4 (convert)].
The circuits are converted.



10.



1

Overview

2

Module Startup

3

Positioning Control Startup

4


Synchronous Control Startup

Appendices

(7) Saving a project

Save a created project.

1. Select [Project] → [Save as], and click [Save] after entering the file name.




[Saving data]

- Parameters and sequence programs of the PLC CPU
- Positioning data and parameters of the Simple Motion module
- Parameters of servo amplifiers

(8) Writing to PLC CPU

Write set parameters and created programs to the PLC CPU.

1. Select [Online] → [Write to PLC CPU] to open the Online Data Operation window.
2. Check the boxes of System parameter/CPU parameter, Module parameter, and Program.
3. Click [Execute] to start writing the selected items to the PLC CPU.
4. Click [Close] after completion of the writing.



3.3 Parameter Settings for Simple Motion Module


(1) Start of Simple Motion module setting function

1. Double click [Simple Motion Module Setting] in the menu of MELSOFT GX Works3 to open the Simple Motion Module Setting Function window.

GX Works3 Menu




[Simple Motion Module Setting Function]



1.

(2) System settings

1. Select the [System Configuration].
2. Set the servo amplifiers according to the machine.
3. Set the details of servo amplifiers.
4. Click [OK], then the set servo amplifier is colored.



1

Overview

2

Module Startup

3

Positioning Control Startup

4

Synchronous Control Startup

Appendices


(3) Parameter settings

[Equipment specifications]

- Machine configuration : Horizontal ball screw
- Unit setting : 0: mm
- Ball screw pitch : 10000.0 [μm]
- Reduction ratio (NL/NM) : 1/2 (Load side [NL]/Motor side [NM])
The load-side ball screw is made to rotate once by rotating the motor twice.
- Encoder resolution : 4194304 [pulse/rev]
- Servo amplifier : MR-J4-10B
- Servo motor : HG-KR series



[Operation procedure]

1. Select [Parameter] in the Menu.
2. Click [Compute Basic Parameters 1] to open the electronic gear calculation screen.
3. Set the parameters according to the machine specification. After the setting, click [Compute Basic Parameters 1] to calculate the electronic gear.
4. Click [OK] to write the electronic gear data to the parameters.



POINT


1. Set [Pr.82 Forced stop valid/invalid selection] to "1: Invalid".
 [Pr.82 Forced stop valid/invalid selection] is set to "valid" as default for safety. Since the machine does not use forced stop, change it to "1: Invalid".
2. Set the "Input type" in [Pr.116 FLS signal selection], [Pr.117 RLS signal selection], [Pr.118 DOG signal selection], and [Pr.119 STOP signal selection].
 Select "15: Invalid" since the machine does not use Data set method, FLS, RLS, and STOP for home position return.



Set common/basic/detailed/home position return/expansion parameters where necessary. (Refer to Appendix 2 for setting examples.)

(4) Servo parameter settings
 [Operation procedure]


1. Select [Servo parameter] in the menu.
2. Click [Basic] in the menu to open [Common - Basic].



3. Set [Rotation direction].

POINT

Set rotation direction according to the machine. Select from [CCW direction during forward pulse input, CW direction during reverse pulse input], or [CW direction during forward pulse input, CCW direction during reverse pulse input].



1
Overview

2
Module Startup

3
Positioning Control Startup


4
Synchronous Control Startup

Appendices

- Set the Servo forced stop selection to "Disabled".

POINT

The "Servo forced stop selection" sets whether to read forced stop input signals via servo amplifiers. This parameter is set to "Enabled (Use forced stop input EM2 or EM1.)" as default for safety. If an error occurs on mechanical system due to crush, etc., establish the absolute position after adjusting the error and ensuring safety. Since the machine in this section does not use forced stop, change it to "1: Disabled".



- Select "Component parts" to open the Component parts window.
- [Absolute position detection system/Incremental system selection]
Select "Disabled (Used in incremental system)" for absolute position detection system selection.
- For home position setting condition, select "1: Not need to pass servo motor Z-phase after power on".

POINT


When "1: Not need to pass servo motor Z-phase after power on" is selected, the home position return can be executed without waiting for the motor to rotate one time or more.

Set servo parameters where necessary.

(5) Positioning data setting


The following explains how to set positioning data through a program example in which the axis travels from the home position (P0) to P1 back and forth.

[Operation example when the axis moves back to the home position (P0) after moving to P1]




[Operation procedure]

1. Select "Axis #1 Positioning Data" in the menu.



2. Select [Data Setting Assistant].
3. Select the positioning control method, and input each item.



Positioning control method: 1-axis linear control (ABS)

Positioning data No.: 1

Positioning address: 100000.0 μm

Command speed: 2000.00 mm/min

Operation pattern: 1: CONT


Acceleration time No.: 0:1000

Deceleration time No.: 0:1000

Dwell time: 0:0 ms

M-code: 0

4. Click [Set]. The Data Setting Assistant window closes, and the positioning data window appears.



Create the positioning data in the same manner for the axis moving back to the home position from P1.


| No. | Operation pattern | Control system | Axis to be interpolated | Acceleration time No. | Deceleration time No. | Positioning address | Arc address | Command speed | Dwell time | M-code |
|-----|-------------------|------------------|-------------------------|-----------------------|-----------------------|---------------------|-------------|----------------|------------|--------|
| 1 | 1: CONT | 01h:ABS Linear 1 | - | 0:1000 | 0:1000 | 100000.0 μm | 0.0 μm | 2000.00 mm/min | 0ms | 0 |
| 2 | 0: END | 01h:ABS Linear 1 | - | 0:1000 | 0:1000 | 0.0 μm | 0.0 μm | 8000 mm/min | 0ms | 0 |

5. Positioning data creation is completed.

(6) Saving a project

Save a created project.

1. Select [Project] - [Save As]. Input a file name, and click [Save].




[Saving data]

- Parameters and sequence programs of the PLC CPU
- Positioning data and parameters of the Simple Motion module
- Parameters of servo amplifiers

(7) Writing to the Simple Motion module

1. Select [Online] → [Write to PLC...] to open the Online Data Operation window on MELSOFT GX Works3.
2. Select the Simple module setting.
3. Click [Execute]. Then, the parameters and data are written to the Simple Motion module via the PLC CPU.
4. The confirmation message window for flash ROM overwriting appears. Click [Yes].
5. Click [Close] to complete the writing to the Simple Motion module.



[Writing data to the Simple Motion module]

- Parameters and servo parameters
- Positioning data and block start data
- Synchronous control parameters and cam data

| | |
|---|-----------------------------|
| 1 | Overview |
| 2 | Module Startup |
| 3 | Positioning Control Startup |
| 4 | Synchronous Control Startup |
| | Appendices |

3.4 Operation Check

The sequence program used in this section is an example using R04CPU and RD77MS4. When another different module is used, the signal assignment differs. Refer to MELSEC iQ-R Simple Motion Module User's Manual (Application) for details of each signal.

3.4.1 JOG operation

(1) Servo ON

Servo amplifiers become servo ON status by turning ON [All axis servo ON (Y1)].


1. Move the PLC CPU switch (RESET/RUN/STOP) to RUN side.

2. Servo ON by a sequence program

Select [Online] → [Monitor] → [Start Monitoring] to switch to the monitoring status.

Move the cursor to the Servo ON req (X7B).

Servo ON req (X7B) is turned ON by double clicking it while pressing SHIFT key.



POINT

Double-clicking a device while pressing SHIFT key changes the status of the device from OFF to ON, and vice versa.

(2) JOG speed settings

Turn ON the JOG Forward Start req and the JOG Reverse start req after setting JOG speed.

1. Double click the "JOG Speed Req" (X60) while pressing SHIFT key.



(3) JOG start

Confirm that the workpiece moves in “+” direction by forward command, and in “-” direction by reverse command.

1. Select axis 1 (X61).

2. Select either the JOG Forward Start req (X6E) or the JOG Reverse Start req (X6F).

Move the cursor to "JOG Forward Start req" or "JOG Reverse Start req", and double click it while pressing SHIFT key.




(4) Confirming JOG operation


Check the JOG operation on the Axis Monitor window.

Signals, such as Forward JOG start and Reverse JOG start, can be added from the Selectable Items on the Axis Monitor window.

1. Click [Select Monitor Item] on the Axis Monitor window.
2. Select items to be added from the Selectable Item list.
3. Select "Cd.181 Forward JOG start", and click [Add].
4. Click [OK] to go back to the Monitor window.



Check each status on the Axis Monitor window during JOG operation.




| Axis monitor | Checking details |
|---|--------------------------------|
| PLC READY (Y0) READY (X0) Synchronization flag (X1) All axes servo ON (Y1) | ON? |
| Md.20: Feed current value Md.21: Machine feed value | - |
| Md.26: Axis operating status Md.28: Axis federate | JOG operation 100.00 mm/min |
| Md.108: Servo status 1: READY ON Md.108: Servo status 1: Servo ON | ON? |
| BUSY | Is Axis1 ON? |
| Cd.181: Forward JOG start | Is the starting axis ON? |
| Cd.182: Reverse JOG start | |

(5) Confirming the motor rotation direction

Switch the motor rotation direction to forward/reverse.

1. Select [Servo Parameter].
2. Select [Basic].
3. Select the servo motor rotation direction according to your machine.



POINT

Set the rotation direction according to the machine.
 Select from [CCW direction during forward pulse input, CW direction during reverse pulse input], or [CW direction during forward pulse input, CCW direction during reverse pulse input].
 After writing servo parameters to the Simple Motion module, cycle the power of both the servo amplifier and the Simple Motion module.

CCW direction during forward pulse input CW direction during forward pulse input

(6) JOG operation check is completed.

3.4.2 Home position return (Establishment of the home position)

There are two types of home position return control:

- Machine home position return which does not use address information to establish the home position.
- Fast home position return which performs positioning by using the coordinate defined by machine home position.

This document explains the method of performing the machine home position return using Data set method.

After setting "9001" as the positioning start No., the home position return is started by turning ON the Positioning start signal.


| Item | Buffer memory | Signal | Description |
|------------------------------|---------------|--------|--|
| Axis 1 positioning start No. | 4300 | - | Set the positioning start No. Set "9001" for machine home position return. |
| Axis 1 positioning start | - | Y10 | Execute the home position return and positioning start. |

POINT

After setting "9001" as the positioning start No., the machine home position return is started by turning ON the Positioning start.


(1) Setting the home position return No.

1. Select the Axis 1. Double click it while pressing SHIFT.



(2) Starting the home position return


1. Set the Positioning start No. (9001) to the buffer memory by double clicking X63 while pressing SHIFT.
2. To start the positioning, double click "Start Positioning req".



- 1 Overview
- 2 Module Startup
- 3 Positioning Control Startup
- 4 Synchronous Control Startup
- Appendices

(3) Confirming the home position return

1. Check the following monitor values and status on the Axis Monitor window.



| Axis monitor | Checking value |
|----------------------------------|----------------|
| Md.20: Feed current value | 0.0 [μm] |
| Md.21: Machine feed value | 0.0 [μm] |
| Md.26: Axis operating status | Waiting |
| Md.28: Axis feedrate | 0.00 [mm/min] |
| Md.31: Status: HPR request flag | OFF |
| Md.31: Status: HPR complete flag | ON |

(4) Home position return check is completed.


3.4.3 Positioning control

This section explains the operation check method for positioning control which performs positioning to a specified position using address information.

Positioning is started by a sequence program or a function block.

In this example, positioning control is started by a function block, and synchronous control by a sequence program.

[Operation example when the axis moves back to the home position (P0) after moving to P1]



Positioning is started by setting the positioning start No. and turning ON the Positioning start signal.

| Item | Buffer memory | Signal | Description |
|------------------------------|---------------|--------|-------------------------------|
| Axis 1 positioning start No. | 4300 | - | Set the positioning start No. |
| Axis 1 positioning start | - | Y10 | Start the positioning. |


(1) Setting the positioning control start No.

1. Set the positioning start No. Double click the Positioning Start Data (X65) while pressing SHIFT.



(2) Positioning start

2. To start the positioning, double click X71 while pressing SHIFT.




(3) Confirmation of axis 1 positioning control

Check that the axis 1 moves for 100.0 mm and goes back to 0.0 mm through the Feed current value for axis 1 on the Axis Monitor window.

Check that the Axis feedrate for axis 1 is equal to the command speed.

Check each monitor value and status through the Axis monitor.



| Axis monitor | Checking details |
|---|------------------|
| Md.20: Feed current value | - |
| Md.21: Machine feed value | - |
| Md.26: Axis operating status | Position control |
| Md.28: Axis feedrate | 2000.00 [mm/min] |
| Md.30: External input signal: Lower limit | ON? |
| Md.30: External input signal: Upper limit | ON? |
| Md.31: Status: HPR request flag | OFF? |

| Module information | Checking details |
|---------------------------|--------------------------|
| PLC READY (Y0) | ON? |
| READY (X0) | |
| Synchronization flag (X1) | |
| All axes servo ON (Y1) | |
| BUSY | Is the starting axis ON? |

(4) Positioning operation check is completed.

4. SYNCHRONOUS CONTROL STARTUP


This chapter describes synchronous control, mainly about the synchronous control parameter, positioning data for synchronous control, and operation check for synchronous control.

Axis 1 operation is the same as that described in Chapter 2.

Refer to Chapter 2 to 3 for details of the parameters and servo parameters.

<Flying Cutter>

Without stopping the conveyor axis (axis 2), cutter axis (axis 1) synchronizes to the movement of the conveyor belt and cuts the work piece evenly in half. After the cut, the cutter axis returns to the wait position. Synchronous control with electronic cam operation is used for the cutter axis.



<Specification>

A one-time belt conveyor rotation generates the conveyor movement for one work piece.

(1) Cutter axis (cam control axis) specification

- Ball screw lead (PB): 10 mm
- Gear ratio of the external reducer: 1/2
- Cam stroke amount: 100.0000 mm

(2) Belt conveyor axis specification


- Roller diameter: 50 mm (Roller circumference $50\text{mm} \times \pi = 157079.6\mu\text{m}$)
- Gear ratio of the external reducer: 1/1 (Directly connect the servo motor to the roller)

<Machine operation pattern>

The cutter axis (axis 1) moves for certain distance while synchronizing to the belt conveyor movement.


The cutter goes down in synchronization with the conveyor by sequence control, and the cutter returns to the original position after the synchronization.

The belt conveyor moves at a constant speed.



4.1 System Configuration

The following shows a system example consisting of the RD77MS, MR-J4-10B, and servo motors.



4.2 Startup Procedure for Synchronous Control

4. SYNCHRONOUS CONTROL STARTUP

4.1 System configuration

4.2 Startup procedure for synchronous control

4.3 Parameter creation for synchronous control

4.3.1 System configuration settings

4.3.2 Parameters and servo parameters settings

4.3.3 Positioning data settings

(1) Positioning data selection

4.3.4 Synchronous control parameter settings

(1) Synchronous parameter settings

(2) Input axis parameter settings

(3) Transition of synchronous control parameter window

(4) Settings for synchronous control parameters and input axis parameters are completed.

4.3.5 Cam data creation

(1) Creating a new cam data

(2) Cam curve creation

4.3.6 Saving a project

4.3.7 Writing to the Simple Motion module

4.4 Operation check for synchronous control

4.4.1 Home position return

4.4.2 Synchronous control start

(1) Start and confirmation of output axis to be synchronized

(2) Start and confirmation of the main shaft (input axis)

(3) Operation check for main shaft (input axis)

4.4.3 Operation check with digital oscilloscope

(1) Start of digital oscilloscope

(2) Selecting probe

(3) Sampling condition settings (No need to change)

(4) Trigger condition settings (No need to change)

(5) Start sampling

(6) Checking cam data

1

Overview

2

Module
Startup

3

Positioning
Control Startup

4


Synchronous
Control Startup

Appendices

4.3 Parameter Creation for Synchronous Control

4.3.1 System configuration settings


Configure a 2-axis system.



4.3.2 Parameters and servo parameters settings

Set parameters and servo parameters for axis 1 and axis 2.

The following shows the setting details of the electronic gear setting for the belt conveyor.



| |
|--|
| [Input] |
| Machine Components: Conveyor |
| Unit Setting: 0:mm |
| Outer diameter of Roll: 50000.0 [μm] |
| Reduction Gear Ratio (NL/NM) |
| Load side [NL]: 1 |
| Motor side [NM]: 1 |
| Encoder resolution: 4194304 |
| [Calculation Result] |
| Unit Setting: 0 mm |
| Number of Pulses per Rotation: 172985333 pulse |
| Movement Amount per Rotation: 6478422.3 μm |
| Unit Magnification: 1: ×1 times |


POINT

When the electronic gear value cannot be divided due to circumference ratio π , it will be automatically calculated to the value with less difference.

4.3.3 Positioning data settings


Create a program in which the belt conveyor (axis 2) moves from the home position to P1.
For axis 1 operated with cam control, create cam data in which the axis 1 synchronizes to the belt conveyor.

[Data example in which the axis moves from the home position to P1]



(1) Positioning data selection

Select the Axis # 2 positioning data in the menu.



<Axis 2 positioning data>

| No. | Operation pattern | Control system | Axis to be interpolated | Acceleration time No. | Deceleration time No. | Positioning address | Arc address | Command speed | Dwell time | M-code |
|-----|-------------------|----------------|-------------------------|-----------------------|-----------------------|---------------------|-------------|----------------|------------|--------|
| 1 | 0: END | INC linear 1 | - | 1:1000 | 1:1000 | 157079.6 μm | 0.0 μm | 2000.00 mm/min | 0ms | 0 |

4.3.4 Synchronous control parameter settings


Set parameters for axis 1 which synchronizes to the input axis (axis 2) feed current value in cam operation.

| Item | Description |
|--------------------------------------|--|
| Input axis parameter | Set the servo input axis type for the main shaft. (Set "1: Feed current value " for axis 2) |
| Axis 1 synchronous control parameter | Set the axis 1 synchronous control parameter. |
| Synchronous control image | The configuration of output axes connected to the main shaft is displayed. The configuration of input/output axes can be checked at a glance. |

(1) Synchronous parameter settings

The following explains the settings that synchronize the axis 1 to the axis 2 feed current value.

1. Select [Main shaft (Main)], and then the [Type] for the Main input axis is selected.
2. Set [Pr.400 Type] to "1: Servo Input Axis", and [Pr.400: Axis No.] to "2".



3. Change the items with red frames as follows.

<Synchronous parameter axis 1>


| Item | | Details | |
|---|---|---|---|
| Main shaft | Main input axis No. | Pr.400: Type | 1: Servo input axis |
| | | Pr.400: Axis No. | 2 |
| | Sub input axis No. | Pr.401:Type | 0: Invalid |
| | | Pr.401: Axis No. | 0 |
| Composite main shaft gear | Pr.402: Main | 1: Input + | |
| | Pr.402: Sub | 0: No input | |
| Main shaft gear | Pr.403: Numerator | 1 | |
| | Pr.404: Denominator | 1 | |
| Main shaft clutch | Main shaft clutch control setting | Pr.405: ON control mode | 0: No clutch (Direct coupled operation) |
| | | Pr.405: OFF control mode | 0: OFF control invalid |
| | | Pr.405: High speed input request signal | 0 |
| Output axis | Cam axis cycle unit setting | Pr.438: Unit setting selection | 0: Use units of main input axis |
| | | Pr.438: Unit | 0mm |
| | | Pr.438: Number of decimal places | 0 |
| | Pr.442: Cam axis length per cycle change setting | 0: Invalid | |
| | Pr.439: Can axis length per cycle | 157.0796mm | |
| | Pr.441: Cam stroke amount | 100000.0µm | |
| | Pr.440: Cam No. | 1 | |
| | Pr.444: Cam axis phase compensation advance time | 0 µs | |
| | Pr.445: Cam axis phase compensation time constant | 10 ms | |
| Pr.446: Synchronous control deceleration time | 0 ms | | |
| Pr.447: Output axis smoothing time constant | 0 ms | | |

(Note): Items without red frames remain as default values.

(2) Input axis parameter settings

The following explains the settings that synchronize the axis 1 to the axis-2 feed current value.

1. Select [Input Axis Parameter].
2. Select [1: Feed Current Value] for [Pr.300 servo input axis type] for axis 2.




<Input axis parameter (axis 2)>

| Item | | Description | |
|------------------|-----------------------|----------------------------------|---|
| Servo input axis | Servo input axis type | 1: Feed current value | |
| | Detail setting | Smoothing time constant | 0ms |
| | | Phase compensation advance time | 0μs |
| | | Phase compensation time constant | 10ms |
| | | Rotation direction restriction | 0: Without rotation direction restriction |


(Note): Items without red frames remain as default values.

- (3) Transition of synchronous control parameter window
 1. Select [Axis # 1 Synchronous Parameter] in the menu.
 - Then, the axis 1 synchronous parameter can be changed.
 2. Click [Synchronous Control Image] to open the image screen.

[Synchronous parameter]



[Synchronous control image]



[Input axis parameter]

Display Filter: Servo Input Axis Parameter Synchronous Parameter Setting Synchronous Control Image

| Item | Axis #1 | Axis #2 | Axis #3 | Axis #4 |
|---|------------------------------------|------------------------------------|------------------------------------|-------------------------------------|
| Servo input axis | | | | |
| Pr.300: Servo input axis type | 0:Invalid | 1:Feed Current Value | 0:Invalid | 0:Invalid |
| Detail setting | | | | |
| Pr. 301: Input smoothing time constant | 0 ms | 0 ms | 0 ms | 0 ms |
| Pr. 302: Phase compensation advance time | 0 μs | 0 μs | 0 μs | 0 μs |
| Pr. 303: Phase compensation time constant | 10 ms | 10 ms | 10 ms | 10 ms |
| Pr. 304: Rotation direction restriction | 0:Without Rotation Direction Re... | 0:Without Rotation Direction Re... | 0:Without Rotation Direction Re... | 0:Without Rotation Direction Res... |


3. Select the main shaft to open the input axis parameter.
Parameters related to the input axis (axis 2) can be set.
- (4) Settings for synchronous control parameters and input axis parameters are completed.

| | |
|---|-----------------------------|
| 1 | Overview |
| 2 | Module Startup |
| 3 | Positioning Control Startup |
| 4 | Synchronous Control Startup |
| | Appendices |

4.3.5 Cam data creation

(1) Creating a new cam data


1. Right click on [Cam Data], and select [Add New Data...] to open the New Data window.
2. Set the cam No.
3. Select "Set by Stroke Ratio" and "Cam Curve" in the Setting Method.
4. Click [OK]. The cam data creation screen appears.



5. Make a rough cam graph by dragging an end of the cam waveform.
6. Based on the rough cam data, modify the end point and stroke, and finish the cam data.

(2) Cam curve creation

A cam data graph can be generated by inputting the end point and the stroke.



<Cam data>

| Section No. | Start point [degree] | End point [degree] | Stroke [%] | Cam curve |
|-------------|----------------------|--------------------|-------------|----------------------|
| 1 | 0.00000 | 2.00000 | 0.0500000 | Constant speed |
| 2 | 2.00000 | 4.00000 | 0.5000000 | Constant speed |
| 3 | 4.00000 | 6.00000 | 1.1000000 | Constant speed |
| 4 | 6.00000 | 8.00000 | 1.9000000 | Constant speed |
| 5 | 8.00000 | 113.59160 | 50.0000000 | Constant speed |
| 6 | 113.59160 | 222.00000 | 98.1000000 | Constant speed |
| 7 | 222.00000 | 224.00000 | 98.9000000 | Constant speed |
| 8 | 224.00000 | 226.00000 | 99.6000000 | Constant speed |
| 9 | 226.00000 | 228.00000 | 99.9500000 | Constant speed |
| 10 | 228.00000 | 229.18320 | 100.0000000 | Constant speed |
| 11 | 229.18320 | 0.00000 | 0.0000000 | Dist. Constant speed |

(3) Cam data creation is completed.

4.3.6 Saving a project

Refer to Section 3.3 "(6) Saving a project".

4.3.7 Writing to the Simple Motion module

Refer to Section 3.3 "(7) Writing to the Simple Motion module".

1 Overview

2 Module Startup

3 Positioning Control Startup

4 Synchronous Control Startup

Appendices

4.4 Operation Check for Synchronous Control


Refer to Chapter 3 for details of JOG operation, home position return, and positioning control. This section explains operation check for synchronous control. Follow the procedure below so that the axis 1 synchronizes to the feed current value of axis 2 with cam operation.

4.4.1 Home position return


Perform home position return for axis 1 and 2. This section explains operation check method for axis 2 home position return. Refer to Chapter 3 for details of the axis-1 home position return operation check.

1. Select axis 2. Double click X62 while pressing SHIFT.
2. Set the Positioning start No. (9001). Double click X63 while pressing SHIFT.
3. Start the positioning. Double click X71 while pressing SHIFT.

[Axis 2 is selected]



[Axis-2 home position return start]




4. Home position return is completed.

4.4.2 Synchronous control start

Set [Cd.380 synchronous control parameter] for each output axis, and start synchronous control. Once the synchronous control starts, output axes operate in synchronization with the input axis operation.

(1) Start and confirmation of output axis to be synchronized


1. Start synchronous control of axis 1. Double click X7D while pressing SHIFT.



2. Check axis-1 BUSY signal

Check the axis operating status and BUSY flag.

When setting H1 to the buffer memory for synchronous control start (U0\G36320), confirm that axis-1 BUSY signal is turned ON.



| Item | Axis 1 |
|------------------------------|---------------------|
| Md.26: Axis operating status | Synchronous control |
| BUSY | Axis 1: ON |

1

Overview

2

Module Startup

3

Positioning Control Startup

4

Synchronous Control Startup

Appendices

(2) Start and confirmation of the main shaft (input axis)


1. Set the axis No. for the main shaft (input axis). Double click X62 while pressing SHIFT.



2. Set the program No. for axis 2. Double click X66 while pressing SHIFT.


3. Start the main shaft (input axis). Double click X71 while pressing SHIFT.

Output axes move synchronizing to the main shaft movement.



(3) Operation check for main shaft (input axis)

Check that the servo motors for axis 1 and 2 start operation.



| | Item | Axis 1 | Axis 2 |
|---|--|--------------------------|---|
| 1 | Md.20: Feed current value Md.21: Machine feed value | - | - |
| 2 | Md.26: Axis operating status Md.28: Axis federate | Synchronous control - | Positioning control 2000.00 [mm/min] |
| 3 | Md.30: External input signal: Lower limit Md.30: External input signal: Upper limit | ON ON | ON ON |
| 4 | BUSY | ON | ON |

1

Overview

2

Module Startup

3

Positioning Control Startup

4

Synchronous Control Startup


Appendices

4.4.3 Operation check with digital oscilloscope

The section explains how to check the cam operation with the assistant function of digital oscilloscope.


(1) Start of digital oscilloscope

1. Select [Digital Oscilloscope] in the menu.




(2) Selecting probe

1. Click [Assistant Screen] to open the Assistant window.
2. Click [Select the probe item to be sampled.] to open the Assistant (Probe Selection).
3. Select [Cam operation] in the List by specified purpose.
4. Select the axis No.



(3) Sampling condition settings (No need to change)


Change the sampling condition where necessary.
In this example, the default values are used.



(4) Trigger condition settings (No need to change)


Set the trigger condition where necessary.
The default values are normally used.

1. Select [Edit] → [Sampling settings] to open the Sampling Setting screen.
2. Select the Trigger Mode from Bit OR, Bit AND, Word OR, or NONE.
3. Select pattern. (Leading edge, trailing edge, change)




(5) Start sampling

RUN: Start sampling.
STOP: Stop sampling.
FREEZE: Sampling pauses.



(6) Checking cam data

Check that the waveform of the created cam data matches that of axis 1 feed current value in digital oscilloscope.



(7) Operation check is completed.

1

Overview

2

Module Startup

3

Positioning Control Startup

4

Synchronous Control Startup

Appendices

APPENDICES


Appendix 1 Simulation

The MELSOFT GX Works3 can simulate the program on a personal computer without an actual machine during the debugging process, shortening the startup time.


(1) Simulation environment settings

1. Select [Debug] → [Simulation] → [Simulation Environment Setting] to open the Simulation Environment Setting window.

Add the Simple Motion module registered in the Module configuration screen.





1.



| | |
|------------|-----------------------------|
| 1 | Overview |
| 2 | Module Startup |
| 3 | Positioning Control Startup |
| 4 | Synchronous Control Startup |
| Appendices | |


(2) Starting MELSOFT GX Works3 simulator

1. Click [Debug] → [Simulation] → [Start Simulation] to open the Online Data Operation screen.
2. Check the boxes for data to be written. Click [Execute].



(3) Starting Simple Motion module simulator


1. After closing the [Online Data Operation] window on the previous page, the message window about the Simple Motion module appears.
2. Click [Online] → [Write to PLC...] to open the Online Data Operation screen.
3. Select [Simple Motion Module Settings].
4. Click [Execute].
5. Click [Yes].




| | |
|------------|-----------------------------|
| 1 | Overview |
| 2 | Module Startup |
| 3 | Positioning Control Startup |
| 4 | Synchronous Control Startup |
| Appendices | |

(4) Reset of Simple Motion module simulation

1. Click [Reset]. STOP is selected from RUN.




2. Select RUN again, and the P.RUN is turned ON.



(5) Debug by simulation

Debug for the Simple Motion module can be executed with GX Simulator3.



Appendix 2 Parameter and Positioning Data

(1) Parameters

| Item | Axis #1 | Axis #2 |
|---|---|--|
| Common Parameter | The parameter does not rely on axis and relate to the... | |
| Pr. 82: Forced stop valid/invalid selection | 1: Invalid | |
| Pr. 24: Manual pulse generator/Incremental Sync. ENC input selection | 0: A-phase/B-phase Mode (4 Multiply) | |
| Pr. 89: Manual pulse generator/Incremental Sync. ENC input type selection | 1: Voltage Output/Open Collector Type | |
| Pr. 96: Operation cycle setting | FFFFh: Automatic Setting | |
| Pr. 97: SSCNET Setting | 1: SSCNET III/H | |
| Pr. 150: Input terminal logic selection | Set the logic of external input signal (proximity dog, external command/switching) from the external devi... | |
| Pr. 151: Manual pulse generator/Incremental Sync. ENC input logic selection | 0: Negative Logic | |
| Pr. 152: Control axis number upper limit | 0 | |
| Pr. 153: External input signal OSC file setting | Set digital filter for each input signal. | |
| Basic parameters 1 | Set according to the machine and applicable motor w... | |
| Pr. 1: Unit setting | 0: mm | 0: mm |
| Pr. 2: No. of pulses per rotation | 172985333 pulse | 172985333 pulse |
| Pr. 3: Movement amount per rotation | 6478422.3 μm | 6478422.3 μm |
| Pr. 4: Unit magnification | 1: x1 Times | 1: x1 Times |
| Pr. 7: Bias speed at start | 0.00 mm/min | 0.00 mm/min |
| Basic parameters 2 | Set according to the machine and applicable motor w... | |
| Pr. 8: Speed limit value | 8000.00 mm/min | 2000.00 mm/min |
| Pr. 9: Acceleration time 0 | 1000 ms | 1000 ms |
| Pr. 10: Deceleration time 0 | 1000 ms | 1000 ms |
| Detailed parameters 1 | Set according to the system configuration when the s... | |
| Pr. 11: Backlash compensation amount | 0.0 μm | 0.0 μm |
| Pr. 12: Software stroke limit upper limit value | 214748364.7 μm | 214748364.7 μm |
| Pr. 13: Software stroke limit lower limit value | -214748364.8 μm | -214748364.8 μm |
| Pr. 14: Software stroke limit selection | 0: Set Software Stroke Limit to Feed Current Value | 0: Set Software Stroke Limit to Feed Current Value |
| Pr. 15: Software stroke limit valid/invalid setting | 0: Valid | 0: Valid |
| Pr. 16: Command in-position width | 10.0 μm | 10.0 μm |
| Pr. 17: Torque limit setting value | 300.0 % | 300.0 % |
| Pr. 18: M-code ON signal output timing | 0: WITH Mode | 0: WITH Mode |
| Pr. 19: Speed switching mode | 0: Standard Speed Switching Mode | 0: Standard Speed Switching Mode |
| Pr. 20: Interpolation speed designation method | 0: Vector Speed | 0: Vector Speed |
| Pr. 21: Feed current value during speed control | 0: Not Update of Feed Current Value | 0: Not Update of Feed Current Value |
| Pr. 22: Input signal logic selection : Lower limit | 0: Negative Logic | 0: Negative Logic |
| Pr. 22: Input signal logic selection : Upper limit | 0: Negative Logic | 0: Negative Logic |
| Pr. 22: Input signal logic selection : Stop signal | 0: Negative Logic | 0: Negative Logic |
| Pr. 22: Input signal logic selection : Proximity dog signal | 0: Negative Logic | 0: Negative Logic |
| Pr. 81: Speed-position function selection | 0: Speed-position Switching Control (INC Mode) | 0: Speed-position Switching Control (INC Mode) |
| Pr. 116: FLS signal selection : Input type | 15: Invalid | 15: Invalid |
| Pr. 116: FLS signal selection : Input terminal | 00h: No Setting | 00h: No Setting |
| Pr. 117: RLS signal selection : Input type | 15: Invalid | 15: Invalid |
| Pr. 117: RLS signal selection : Input terminal | 00h: No Setting | 00h: No Setting |
| Pr. 118: DOG signal selection : Input type | 15: Invalid | 15: Invalid |

1

Overview

2

Module Startup

3

Positioning Control Startup

4

Synchronous Control Startup

Appendices

| Item | Axis #1 | Axis #2 |
|---|---|--|
| Pr. 118:DOG signal selection : Input terminal | 00h:No Setting | 00h:No Setting |
| Pr. 119:STOP signal selection : Input type | 15:Invalid | 15:Invalid |
| Pr. 119:STOP signal selection : Input terminal | 00h:No Setting | 00h:No Setting |
| ▣ Detailed parameters 2 | Set according to the system configuration when the s... | |
| Pr. 25:Acceleration time 1 | 1000 ms | 1000 ms |
| Pr. 26:Acceleration time 2 | 1000 ms | 1000 ms |
| Pr. 27:Acceleration time 3 | 1000 ms | 1000 ms |
| Pr. 28:Deceleration time 1 | 1000 ms | 1000 ms |
| Pr. 29:Deceleration time 2 | 1000 ms | 1000 ms |
| Pr. 30:Deceleration time 3 | 1000 ms | 1000 ms |
| Pr. 31:JOG speed limit value | 200.00 mm/min | 200.00 mm/min |
| Pr. 32:JOG operation acceleration time selection | 0: 1000 | 0: 1000 |
| Pr. 33:JOG operation deceleration time selection | 0: 1000 | 0: 1000 |
| Pr. 34:Acceleration/deceleration process selection | 0:Trapezoidal Acceleration/Deceleration Process | 0:Trapezoidal Acceleration/Deceleration Process |
| Pr. 35:S-curve ratio | 100 % | 100 % |
| Pr. 36:Rapid stop deceleration time | 1000 ms | 1000 ms |
| Pr. 37:Stop group 1 rapid stop selection | 0:Normal Deceleration Stop | 0:Normal Deceleration Stop |
| Pr. 38:Stop group 2 rapid stop selection | 0:Normal Deceleration Stop | 0:Normal Deceleration Stop |
| Pr. 39:Stop group 3 rapid stop selection | 0:Normal Deceleration Stop | 0:Normal Deceleration Stop |
| Pr. 40:Positioning complete signal output time | 300 ms | 300 ms |
| Pr. 41:Allowable circular interpolation error width | 10.0 μm | 10.0 μm |
| Pr. 42:External command function selection | 0:External Positioning Start | 0:External Positioning Start |
| Pr. 83:Speed control 10x multiplier setting for degree axis | 0:Invalid | 0:Invalid |
| Pr. 84:Restart permissible value range when servo OFF to ON | 0 pulse | 0 pulse |
| Pr. 90:Operation setting for SPD-TRQ Cont. mode : Torque initial value selection | 0:Command Torque | 0:Command Torque |
| Pr. 90:Operation setting for SPD-TRQ Cont. mode : Speed initial value selection | 0:Command Speed | 0:Command Speed |
| Pr. 90:Operation setting for SPD-TRQ Cont. mode : Condition selection at mode switching | 0:Switching Conditions Valid at Mode Switching | 0:Switching Conditions Valid at Mode Switching |
| Pr. 95:External command signal selection | 0:Not Used | 0:Not Used |
| Pr. 122:Manual pulse generator speed limit mode | 0:Do Not Execute Speed Limit | 0:Do Not Execute Speed Limit |
| Pr. 123:Manual pulse generator speed limit value | 200.00 mm/min | 200.00 mm/min |
| ▣ HPR basic parameters | Set the values required for carrying out HPR control (...) | |
| Pr. 43:HPR method | 6:Data Set Method | 6:Data Set Method |
| Pr. 44:HPR direction | 0:Forward Direction (Address Increase Direction) | 0:Forward Direction (Address Increase Direction) |
| Pr. 45:HP address | 0.0 μm | 0.0 μm |
| Pr. 46:HPR speed | 1000.00 mm/min | 1000.00 mm/min |
| Pr. 47:Creep speed | 0.01 mm/min | 0.01 mm/min |
| Pr. 48:HPR retry | 0:Do Not Retry HPR with Limit Switch | 0:Do Not Retry HPR with Limit Switch |
| ▣ HPR detailed parameters | Set the values required for carrying out HPR control (...) | |
| Pr. 50:Setting for the movement amount after proximity dog ON | 0.0 μm | 0.0 μm |

| | | |
|--|--|---------------------------------------|
| Pr.51:HPR acceleration time selection | 0:1000 | 0:1000 |
| Pr.52:HPR deceleration time selection | 0:1000 | 0:1000 |
| Pr.53:HP shift amount | 0.0 μm | 0.0 μm |
| Pr.54:HPR torque limit value | 300.0 % | 300.0 % |
| Pr.55:Operation setting for incompletion of HPR | 0:Positioning Control is Not Executed | 0:Positioning Control is Not Executed |
| Pr.56:Speed designation during HP shift | 0:HPR Speed | 0:HPR Speed |
| Pr.57:Dwell time during HPR retry | 0 ms | 0 ms |
| Pr.86:Pulse conversion unit : HPR request setting | 0:Turn HPR Request ON at Servo OFF | 0:Turn HPR Request ON at Servo OFF |
| Pr.87:Pulse conversion unit : Waiting time after clear signal output | 0 ms | 0 ms |
| Expansion parameters | Set according to the system configuration when the s... | |
| Pr.91:Optional data monitor : Data type setting 1 | 0:No Setting | 0:No Setting |
| Pr.92:Optional data monitor : Data type setting 2 | 0:No Setting | 0:No Setting |
| Pr.93:Optional data monitor : Data type setting 3 | 0:No Setting | 0:No Setting |
| Pr.94:Optional data monitor : Data type setting 4 | 0:No Setting | 0:No Setting |

(2) Positioning data

<Axis-1 positioning data>

| No. | Operation pattern | Control system | Axis to be interpolated | Acceleration time No. | Deceleration time No. | Positioning address | Arc address | Command speed | Dwell time | M-code |
|-----|-------------------|---------------------|-------------------------|-----------------------|-----------------------|---------------------|-------------|-----------------------|------------|--------|
| 1 | 1: CONT | ABS linear 1 | - | 1:1000 | 1:1000 | 100000.0 μm | 0.0 μm | 2000.00 mm/min | 0ms | 0 |
| 2 | 0: END | ABS linear 1 | - | 1:1000 | 1:1000 | 0.0μm | 0.0 μm | 8000.00 mm/min | 0ms | 0 |

<Axis-2 positioning data>

| No. | Operation pattern | Control system | Axis to be interpolated | Acceleration time No. | Deceleration time No. | Positioning address | Arc address | Command speed | Dwell time | M-code |
|-----|-------------------|---------------------|-------------------------|-----------------------|-----------------------|---------------------|-------------|-----------------------|------------|--------|
| 1 | 0:END | INC linear 1 | - | 1:1000 | 1:1000 | 157079.6 μm | 0.0 μm | 2000.00 mm/min | 0ms | 0 |

Appendix 3 Sample Program


⚠ CAUTION

- The sequence program in the appendix is a program example used in this Quick Start Guide. When applying the program examples provided in this document to an actual system, ensure the applicability and confirm that it will not cause system control problems.

(1) Devices used

| Classification | Device No. | Signal name | Signal |
|----------------|------------|------------------------------------|------------------------------|
| Input | X60 | JOG speed Req | Input module ↓ PLC CPU |
| | X61 | Axis 1 | |
| | X62 | Axis 2 | |
| | X63 | Home Position Return Data | |
| | X65 | Positioning Start Data | |
| | X66 | Synchronous Positioning Start data | |
| | X6E | JOG Forward Start req | |
| | X6F | JOG Reverse Start req | |
| | X71 | Start Positioning req | |
| | X7B | Servo ON req | |
| | X7D | Synchronous axis set | |
| | X7E | Error reset | |
| | X7F | Stop | |
| Output | Y0 | PLC READY | PLC CPU ↓ RD77MS |
| | Y1 | All axis servo ON | |
| | Y10 | Positioning start (Axis#1 - 16) | |
| | Y11 | Positioning start (Axis#1 - 16) | |

(2) Sequence program example



1

Overview

2

Module Startup

3


Positioning Control Startup

4

Synchronous Control Startup

Appendices

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
|----|--|--|--|--|--|---|---------------------------|---|---|-------|-------|---|
| 13 | bJogFor... X6E JOG Forward Start req | | | | | Bi_bFJog Forward run JOG command | o_uErrId:UW Error code | uwErrId [D12] JOG Error code | | | | |
| 14 | bJogRe... X6F JOG Reverse Start Req | | | | | Bi_bRJog Reverse run JOG command | | | | | | |
| 15 | | | | | i_JogS... [D10] Jog Speed data memo | UDi_udJog... Cd.17:JOG speed | | | | | | |
| 16 | | | | | [K0] UW:uInching Cd.16: Inching movement amount | | | | | | | |
| 17 | bPositi... X65 (400) Positioning Start Data | | | | | | | | | MOV P | K1 | uwPositi... D16 Positioning Start No |
| 18 | bSyncP... X66 (404) Synchrono us Positioning Start data | | | | | | | | | MOV P | K1 | uwPositi... D16 Positioning Start No |
| 19 | bHomeP... X63 (408) Home Position return Data | | | | | | | | | MOV P | K9001 | uwPositi... D16 Positioning Start No |
| 20 | bStartp... X71 (412) Start Positioning req | bDuring... M81 JOG/Inchi ng Operation flag | RD77.1... Y10 RW:Positi ng start (Axis#1- #16) | RD77.1... DX10 R:BUSY (Axis#1- #16) (Direct) | = | K1 | iAxisNo D14 Axis No | | | | SET | bPositi... M80 Positioning Start Request |
| 21 | | | RD77.1... Y11 RW:Positi ng start (Axis#1- #16) | RD77.1... DX11 R:BUSY (Axis#1- #16) (Direct) | = | K2 | iAxisNo D14 Axis No | | | | | |
| 22 | (430) | | | | | M_RD77_StartPositionin... (M Positioning start FB | | | | | | |
| 23 | bPositi... M80 Positioning Start Request | = | K1 | iAxisNo D14 Axis No | | Bi_bEN | o_bENO:B | | | | | bStartEND M85 Positioning Start Operation flag |
| 24 | | | | | RD77.1 [] Module label | DUTi_stMo... Module label | o_bOK:B | | | | | bStartOK M86 Positioning Start OK |



1

Overview

2

Module Startup

3

Positioning Control Startup

4

Synchronous Control Startup


Appendices

| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
|----|-------|---|---|---|---|---|---|---|---|------|----|--|
| 36 | | RD77.1... X11  R.BUSY (Axis#1- #16) | | | | | | | | | | RD77.1... U0W36...  |
| 37 | (875) | bSynchr... X7D  Synchrono us Axis Set | | | | | | | | MOVP | H1 | RD77.1... U0W36... RW:Synchr onous control start(Dir... |
| 38 | (881) | bSynchr... X7D  Synchrono us Axis Set | | | | | | | | MOVP | H0 | RD77.1... U0W36... RW:Synchr onous control start(Dir... |
| 39 | (887) | | | | | | | | | | | [END] |

Mitsubishi Servo System Controllers Quick Start Guide

| Country/Region | Sales office | Tel/Fax |
|----------------|---|---|
| USA | Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A. | Tel : +1-847-478-2100 Fax : +1-847-478-2253 |
| Mexico | Mitsubishi Electric Automation, Inc. Mexico Branch Mariano Escobedo #69, Col.Zona Industrial, Tlalnepantla Edo. Mexico, C.P.54030 | Tel : +52-55-3067-7500 Fax : - |
| Brazil | Mitsubishi Electric do Brasil Comercio e Servicos Ltda. Rua Jussara, 1750- Bloco B Anexo, Jardim Santa Cecilia, CEP 06465-070, Barueri - SP, Brasil | Tel : +55-11-4689-3000 Fax : +55-11-4689-3016 |
| Germany | Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8, 40880 Ratingen, Germany | Tel : +49-2102-486-0 Fax : +49-2102-486-1120 |
| UK | Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, UK-Hatfield, Hertfordshire, AL10 8XB, U.K. | Tel : +44-1707-28-8780 Fax : +44-1707-27-8695 |
| Italy | Mitsubishi Electric Europe B.V. Italian Branch Centro Direzionale Colleoni - Palazzo Sirio, Viale Colleoni 7, 20864 Agrate Brianza (Milano), Italy | Tel : +39-039-60531 Fax : +39-039-6053-312 |
| Spain | Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi, 76-80-Apdo. 420, 08190 Sant Cugat del Valles (Barcelona), Spain | Tel : +34-935-65-3131 Fax : +34-935-89-1579 |
| France | Mitsubishi Electric Europe B.V. French Branch 25, Boulevard des Bouvets, 92741 Nanterre Cedex, France | Tel : +33-1-55-68-55-68 Fax : +33-1-55-68-57-57 |
| Czech Republic | Mitsubishi Electric Europe B.V. Czech Branch Avenir Business Park, Radlicka 751/113e, 158 00 Praha 5, Czech Republic | Tel : +420-251-551-470 Fax : +420-251-551-471 |
| Poland | Mitsubishi Electric Europe B.V. Polish Branch ul. Krakowska 50, 32-083 Balice, Poland | Tel : +48-12-347-65-00 Fax : +48-12-630-47-01 |
| Russia | Mitsubishi Electric (Russia) LLC St. Petersburg Branch Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benua", office 720; 195027 St. Petersburg, Russia | Tel : +7-812-633-3497 Fax : +7-812-633-3499 |
| Sweden | Mitsubishi Electric Europe B.V. (Scandinavia) Fjellievagen 8, SE-22736 Lund, Sweden | Tel : +46-8-625-10-00 Fax : +46-46-39-70-18 |
| Turkey | Mitsubishi Electric Turkey A.S. Umraniye Branch Serifali Mahallesi Nutuk Sokak No:5, TR-34775 Umraniye / Istanbul, Turkey | Tel : +90-216-526-3990 Fax : +90-216-526-3995 |
| UAE | Mitsubishi Electric Europe B.V. Dubai Branch Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E. | Tel : +971-4-3724716 Fax : +971-4-3724721 |
| South Africa | ADROIT TECHNOLOGIES 20 Waterford Office Park, 189 Witkoppen Road, Fourways, South Africa | Tel : +27-11-658-8100 Fax : +27-11-658-8101 |
| China | Mitsubishi Electric Automation (China) Ltd. Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Shanghai, China | Tel : +86-21-2322-3030 Fax : +86-21-2322-3000 |
| Taiwan | SETSUYO ENTERPRISE CO., LTD. 6F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan | Tel : +886-2-2299-2499 Fax : +886-2-2299-2509 |
| Korea | Mitsubishi Electric Automation Korea Co., Ltd. 7F-9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul 07528, Korea | Tel : +82-2-3660-9510 Fax : +82-2-3664-8372/8335 |
| Singapore | Mitsubishi Electric Asia Pte. Ltd. 307 Alexandra Road, Mitsubishi Electric Building, Singapore 159943 | Tel : +65-6473-2308 Fax : +65-6476-7439 |
| Thailand | Mitsubishi Electric Factory Automation (Thailand) Co., Ltd. 12th Floor, SV.City Building, Office Tower 1, No. 896/19 and 20 Rama 3 Road, Kwaeng Bangpongpan, Khet Yannawa, Bangkok 10120, Thailand | Tel : +66-2682-6522 to 6531 Fax : +66-2682-6020 |
| Indonesia | PT. Mitsubishi Electric Indonesia Gedung Jaya 11th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia | Tel : +62-21-3192-6461 Fax : +62-21-3192-3942 |
| Vietnam | Mitsubishi Electric Vietnam Company Limited Unit 01-04, 10th Floor, Vincom Center, 72 Le Thanh Ton Street, District 1, Ho Chi Minh City, Vietnam | Tel : +84-8-3910-5945 Fax : +84-8-3910-5947 |
| India | Mitsubishi Electric India Pvt. Ltd. Pune Branch Emerald House, EL-3, J Block, M.I.D.C., Bhosari, Pune - 411026, Maharashtra, India | Tel : +91-20-2710-2000 Fax : +91-20-2710-2100 |
| Australia | Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia | Tel : +61-2-9684-7777 Fax : +61-2-9684-7245 |

Mitsubishi Electric Corporation Nagoya Works is a factory certified for ISO 14001 (standards for environmental management systems) and ISO 9001 (standards for quality assurance management systems).



MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS: 1-14, YADA-MINAMI 5, HIGASHI-KU, NAGOYA, JAPAN